

Nailstrip No. 8001

Subject: Substrate Preparation and Installation

Date: April 2011 (Revised January 2019)

ThermaFoam R-Control Nailstrip is an ideal insulation and nailable surface when applied over structural walls such as poured concrete, concrete block, brick, wood and steel framing.

ThermaFoam R-Control Nailstrip must be applied to a solid sound structural substrate. Prior to installing ThermaFoam R-Control Nailstrip, examine all areas of the substrate to make certain that adequate mechanical attachment can be achieved. Areas that are not adequately strong must be repaired or replaced. The substrate must be free of all contaminants that may cause damage to ThermaFoam R-Control Nailstrip or inhibit attachment. The substrate surface additionally must be flat. Remove bumps, protrusions, and irregularities that may interfere with installation. Provide framing as needed around fixtures, pipes, services boxes, etc. as required.

The substrate should be plumb and square. If the substrate is out of square, provide square and plumb framing members at the boundary of the substrate prior to installation of ThermaFoam R-Control Nailstrip.

If the substrate is not plumb determine the out of plane areas prior to installation and use the following general guidelines:

Use Loctite® PL® 300 VOC Foamboard or similar polystyrene compatible adhesive to apply 3" diameter pillows of adhesive to the substrate on 12" centers vertically and horizontally.

Note: Apply the adhesive thicker over indented areas and thinner in protruding areas.

Apply the ThermaFoam R-Control Nailstrip to the substrate and press firmly against the adhesive.

Use a 6' flat edge board or similar to tamp the entire face of the ThermaFoam R-Control Nailstrip until it is plumb and square.

Apply ThermaFoam R-Control fasteners in sufficient number to temporarily hold the ThermaFoam R-Control Nailstrip in place without movement.

After the adhesive has sufficiently cured, install Foam-Control fasteners per the specified installation pattern.

Note: Structural substrates that are severely out of plumb may require longer screws at the "kicked in" areas.

Once installation of the ThermaFoam R-Control Nailstrip is complete, attach appropriate cladding materials per the cladding manufacturers recommended installation guidelines.



www.powerfoam.com